

Apple Restoration CD - Read Me File System Software May 1995

This file contains a listing of all the software configurations available on the CD. In addition, this file contains important information about the release of the Apple Restoration CD that supersedes information in the *Apple Restoration CD User's Guide*.. Refer to the on-line descriptions and those provided here when selecting a software configuration to restore on Macintosh computers.

Restoration CD, System Software May 1995 Configuration Information

Using the Restoration SW installer on the Apple Restoration CD, you can choose the software you want to reinstall on a Macintosh computer. The System Software Apple Restoration CD provides the following software configurations:

Disk 1, May 1995

Description	Configuration Number	Description	Configuration Number		
Desktop Computers		PowerBook Computers			
6.0.8 for SE, Classic, SE/30, LC, LCII, IIsi, IIfx, IIci, II, IIfx, IIfx	694-0222	7.5.1 for PB520, PB520c, PB540, PB540c w/Modem	694-0435		
7.0.1 for SE, Classic, SE/30, LC, LCII, IIsi, IIfx, IIci, II, IIfx, Classic II, Q700, Q900, Q950	694-0223	7.1.1 for PB520, PB520c, PB540, PB540c w/7.5 & System 7.5 Update 1.0 install folders	694-0436		
7.1 for Centris 660 _{AV} , Quadra 660 _{AV} , Quadra 840 _{AV}	694-0250*	7.5.1 for PB280, 280c w/modem	694-0437		
7.1 for Classic II, LCII, IIsi	694-0015-B*	7.1.1 for PB280, PB280c w/7.5 & System 7.5 Update 1.0 install folders	694-0438		
7.1 for Color Classic	694-0218*	7.1.1 for PB 150 w/7.5 and System 7.5 Update 1.0 install folders	694-0434		
7.1 for Macintosh TV	694-0216*	Apple Product Installers	Version		
7.1 for Quadra 950 Publishing Configuration	694-0165*				
7.1. for Quadra 950	694-0249*				
PowerBook Computers					
6.0.8 for Macintosh Portable, PowerBook 100	694-0222			Apple AudioVision Software	1.0.2
7.0.1 for PB 100, 140, 145, 145B, 170	694-0223			Apple Color StyleWriter Software	1.5
7.1 for Duo 210, 230	694-0073*†			Apple IIfx card Software	2.2.1
7.1 for Duo 250, 270c	694-0221-B*†			Apple CD-ROM Software	5.0.4
7.1 for PB 140, 145, 170	694-0015-B*			Apple Telecom Software	2.0
7.1 for PB 145B	694-0075*			Apple LaserWriter 8 Software	8.1.1
7.1 for PB 160, 165, 165c, 180, 180c	694-0215*†			Apple LaserWriter Select 300 Software	1.2
Software for DuoDock	694-0054			Apple LaserWriter Select 310 Software	1.0.1
7.1.1 for PB 520, 520c, 540, 540c	694-0299			Apple Personal LaserWriter 320	1.0.1
7.1.1 for PB 520, 520c, 540, 540c with PowerPort 500 modem	694-0298			Apple LaserWriter Pro 810f	1.0.1
7.1.1 for PB 280, 280c	694-0301†			Apple LaserWriter Select 360f	1.0.1
7.1.1 for PB 150	694-0277			Apple Network Software Installer	1.5.1
Other				Apple OneScanner Software	2.0.2
Apple External Hard Drive	694-0196			Apple Portable StyleWriter Software	1.0.1
		Apple StyleWriter I/II/1200 Software	1.0		
		Apple System 7.1	7.1		
		Apple System Update	3.0		
		Apple System 7.5 Update 1.0	1.0		
		Power Macintosh Upgrade Card Software	1.0*		

* Apple recommends that you install the System Update 3.0 from the CD after you install this configuration.

† Apple recommends that you install Express Modem Software after installing this configuration if the computer has an Express modem installed.

‡ Apple recommends that you install Apple CD-ROM Software after installing this configuration if the computer has a CD-ROM drive.

§ Apple recommends that you install the AppleShare 4.0.1 Tune-Up from the CD after you install this configuration.

|| Apple recommends that you use the LaserWriter 8 driver for the LaserWriter, LaserWriter Plus, LaserWriter II, II NT, II NTX, IIf, IIfg, Personal LaserWriter NT, Personal LaserWriter NTR, LaserWriter Pro, Pro 630, Pro 810, and LaserWriter Select 360.

Disk 2, May 1995

Desktop Computers

7.1 for LCIII, LC475, LC520, LC550 LC575, Quadra 605	694-0294*
7.1 for Q700, Q900, C610, C650, IIfx, IIfi, IIfi	694-0085*‡
7.1 for Quadra 610, Quadra 650, Quadra 800	694-0251*
7.1.2 for Power Macintosh 6100, 7100, 8100	694-0292
7.1.2 for Power Macintosh w/SoftWindows	694-0293
7.5 for Power Macintosh 6100, 7100, 8100 w/SoftWindows	694-0326
7.5.1 for Power Macintosh 6100/66	694-0440
7.5.1 for Power Macintosh 7100/8100	694-0441
7.5.1 for Power Macintosh DOS compatible	694-0456
7.5.1 for Power Macintosh 5200/6200	694-0447

Apple Product Installers

Apple CD-ROM Software	5.0.4
Apple Network Software Installer	1.5.1
Apple System Update	3.0
Apple System 7.5 Update 1.0	1.0

Disk 3, May 1995

Desktop Computers

7.1 for Quadra 610 DOS compatible	694-0268-B*
7.5.1 for LC630 DOS compatible	694-0433
7.5 for LC 580, 630, Quadra 630	694-0475‡#
7.5 for LCIII, LC475, LC520, LC550 LC575, Quadra 605	694-0424‡#

Apple Business Systems Software

7.1 for Apple Workgroup Server 60, 80 w/AppleShare 4.0	694-0236*‡§
7.1.2 for Apple Workgroup Server 9150	694-0284
7.1.2 for Apple Workgroup Server 9150 w/AppleShare 4.0.2	694-0286
7.1.2 for Apple Workgroup Server 6150, 8150 w/AppleShare 4.0.2	694-0287
7.5.1 for Workgroup Server 6150, 8150, 9150	694-0460
7.5.1 for Workgroup Server 6150, 8150, 9150 w/AppleShare 4.1	694-0454

Apple Product Installers

AppleShare 4.0.1 Tune Up	4.0.1
Apple CD-ROM Software	5.0.4
Apple Network Software Installer	1.5.1
Apple System Update	3.0
Apple System 7.5 Update 1.0	1.0

* Apple recommends that you install the System Update 3.0 from the CD after you install this configuration.

† Apple recommends that you install Express Modem Software after installing this configuration if the computer has an Express modem installed.

‡ Apple recommends that you install Apple CD-ROM Software after installing this configuration if the computer has a CD-ROM drive.

§ Apple recommends that you install the AppleShare 4.0.1 Tune-Up from the CD after you install this configuration.

|| Apple recommends that you use the LaserWriter 8 driver for the LaserWriter, LaserWriter Plus, LaserWriter II, II NT, II NTX, IIf, IIfg, Personal LaserWriter NT, Personal LaserWriter NTR, LaserWriter Pro, Pro 630, Pro 810, and LaserWriter Select 360.

Apple recommends that you install the System 7.5 Update 1.0 from the CD after you install this configuration.

Important Information

1. You can use the Apple Restoration CD on the Apple CD SC Plus and newer Apple CD-ROM drives. If you are not booting from the Apple Restoration CD, you also need the appropriate CD-ROM software driver installed on your Macintosh computer.
2. You cannot boot from the Apple Restoration CD on Macintosh SE, SE/30, Classic, II, IIx, or IICx computers. With these computers, start your Macintosh with a bootable hard drive and then run the Restoration CD installer program from the Other Items window that appears in the Finder.
3. If you're restoring software to a blank replacement hard drive in a single-drive system, the computer should boot from the Apple Restoration CD after a few seconds. If the computer has an internal hard drive capable of booting the computer, press and hold down the Shift, Option, Command, and Delete keys while starting the system. If the computer has multiple SCSI hard drives that are set up as bootable startup disks, disconnect or leave them powered off while using the Apple Restoration CD. Here are a few other notes about booting from the Apple Restoration CD:
 - a. On Macintosh SE, SE/30, II, IIx, IICx, IICi, IIfx, IIsi, and Performa 200, 400, 405, and 430 computers, pressing and holding down the Shift, Option, Command, and Delete keys during startup disables the hard drive installed as SCSI device 0.
 - b. On all other computers except those listed in items 2 and 3a, pressing and holding down the Shift, Option, Command, and Delete keys during startup disables the hard drive chosen with the Startup Disk control panel. If no disk was chosen with the Startup Disk control panel, the computer will either disable the hard drive installed as SCSI device 0 or the key sequence will have no effect (depending on the model of computer).
 - c. In general, if you are using an Apple CD 300 player and you set the CD-ROM drive's SCSI device number to a higher number than a bootable hard drive, the computer should boot from the CD-ROM drive. If other devices are starting the computer, either disconnect them, set the CD-ROM drive to be the startup disk, or specify a hard drive to be the startup disk and then use the Shift-Option-Command-Delete key sequence to disable the drive. If the computer still attempts to boot from SCSI device 0, even after using the Shift-Option-Command-Delete key sequence, you can reset the startup disk to SCSI device 0 by clearing parameter RAM (pressing and holding down Option-Command-P-R keys while starting up your system). Note, however, that clearing parameter RAM also clears other user settings.

Apple, the Apple logo, Apple IIGS, AppleCD SC, AppleLink, AppleShare, AppleTalk, A/UX, DuoDisk, EtherTalk, FDHD, GS/OS, HyperCard, ImageWriter, LaserWriter, Lisa, LocalTalk, Mac, Macintosh, StyleWriter, and TokenTalk are trademarks of Apple Computer, Inc., registered in the U.S. and other countries.

Classic is a registered trademark licensed to Apple Computer, Inc.

AppleCD, AppleColor, Apple Desktop Bus, AppleDesign, AppleFund, AppleOrder, Apple SuperDrive, Apple TechStep, AppleWriter, At Ease, AudioVision, Balloon Help, DocViewer, FinePrint, GeoPort, GrayShare, LaserWriter Select, Macintosh Centris, Macintosh Duo, Macintosh Quadra, MacTest, Newton, OneScanner, Performa, PhotoGrade, PowerBook, PowerBook Duo, QuickDraw, QuickTime, System 7, and TrueType are trademarks of Apple Computer, Inc.

Apple Assurance and AppleCare are service marks of Apple Computer, Inc.

PostScript is a trademark of Adobe Systems Incorporated, which may be registered in certain jurisdictions. Helvetica, Times, and Palatino are registered trademarks of Linotype Company. ITC Avant Garde, ITC Bookman, ITC Garamond, ITC Zapf Chancery, and ITC Zapf Dingbats are registered trademarks of International Typeface Corporation. NuBus is a trademark of Texas Instruments. PowerCD is a trademark of ZCI, Inc., Dallas, Texas. Trinitron is a registered trademark of Sony Corporation.

All other trademarks and registered trademarks are the property of their respective companies.