



Software

Tank Top

Iron-Ons

CD-ROM KIT




Alexandra has arrived!

Ages 8
& Up

21393

CD-ROM
WINDOWS® 95
MACINTOSH®





Welcome

Design and make iron-on transfers for a cool tank top and other wearable fashions! With Fashion Magic™ TankTop Iron-Ons CD-ROM Kit, you can design and create your own fashion statement with your computer and color inkjet printer. The software includes lots of cool art and the ability to import photos for creating fun customized wearable art. Everything you need to create your designs, including the fashionable tanktop and iron-on paper is included in the kit.

© 1998 Mattel, Inc. El Segundo, CA 90245 U.S.A. **PRINTED IN U.S.A.** Manufactured for Mattel. All Rights Reserved. Trademarks designated by ® and ™ are trademarks of Mattel, Inc. in the U.S. and/or other countries, except for the following: Microsoft and Windows are either registered trademarks or trademarks of Microsoft Corporation in the U.S. and/or other countries; Macintosh and Mac are registered trademarks of Apple Computer, Inc. in the U.S. and/or other countries; Pentium is a registered trademark of Intel Corporation; PowerPC is a registered trademark of IBM Corporation in the United States; EPSON Stylus is a registered trademark of Seiko Epson Corporation, registered in the U.S. and/or other countries; HP and DeskJet are registered trademarks of Hewlett-Packard Corporation; Canon is a registered trademark and Bubble Jet is a trademark of Canon, Inc.; Lexmark is a registered trademark of Lexmark International, Inc.; QuickTime and the QuickTime logo are trademarks used under license. QuickTime is registered in the U.S. and other countries.

(See product 'Read Me' file for additional trademark and copyright notices)

Your use of the CD-ROM is subject to a License Agreement printed in this User Guide.

License Agreement

MATTEL, INC. "FASHION MAGIC™ TANKTOP IRON-ONS CD-ROM KIT" MULTIMEDIA PROGRAM LICENSE AGREEMENT

PLEASE READ THIS AGREEMENT CAREFULLY BEFORE USING THE PROGRAM. BY USING THE PROGRAM, YOU AGREE TO ABIDE BY THESE TERMS AND APPLICABLE COPYRIGHT LAWS. IF YOU DO NOT AGREE, PLEASE PROMPTLY RETURN THE PROGRAM FOR A FULL REFUND OF THE AMOUNT YOU PAID.

As between You and Mattel, Inc. or its subsidiaries or affiliates ("Mattel"), the Program is owned by Mattel, and is licensed to You, not sold.

The term "Program" means the original program and all whole or partial copies of it, including portions merged into other programs. The Program is copyrighted and includes executable code and audio/visual content (A/V Content). The term "A/V Content" means any image, text, recording, picture or other audio and/or visual work.

License. Mattel grants You a nonexclusive license for the Program.

Under this license You may:

- 1 Use the Program on only one machine at any one time;
- 2 Make one copy of the Program for backup purposes only; and
- 3 Transfer all of Your license rights in the Program to another party if and only if (a) You transfer this License Agreement and all other documentation provided with the Program, and the complete unaltered Program to the other party, (b) You destroy all copies of the Program in your possession, and (c) the other party reads and agrees to be bound by the terms of this License Agreement. It is your responsibility to ensure that all of these conditions are met. The rights licensed to You under this License Agreement are then terminated with respect to You and transferred to the other party, who, in order to be a valid user of the Program is then subject to all of the terms and conditions of this License Agreement.

You must reproduce the copyright notice(s) and any other notice of ownership on each copy or partial copy of the Program.

You may not:

- 1** Use, copy, or transfer the Program (including any A/V Content) except as provided in this License Agreement;
- 2** Modify or adapt any A/V Content without the express written consent of Mattel or as permitted by law;
- 3** Reverse assemble, reverse compile or otherwise reverse engineer or translate the Program or attempt to derive source code from the object code version of the Program (except as allowed by mandatory provisions, if any, of the jurisdiction in which You obtained this License);
- 4** Sublicense, rent, or lease the Program;
- 5** Remove any proprietary notices or labels in the Program;
- 6** Sell any items made using this Program or use the Program as part of a service bureau;
- 7** Use this Program on any network or download, upload or exhibit the Program via the Internet/World Wide Web/WebTV/satellite or any similar technology; or
- 8** Use this Program in a country other than the country in which it was purchased.

General. Your license will terminate automatically (which means that all rights licensed to You under this License Agreement terminate) without notice from Mattel if You fail to comply with the terms of this License Agreement. In such event, You must destroy or disable all Your copies of the Program. You agree to comply with all applicable import and export laws and regulations. This License Agreement shall be governed by, and construed in accordance with, the laws of the State of California without giving effect to any principles of conflicts of law. The provisions of this License Agreement are severable; if any provision is held to be invalid or unenforceable, it shall not affect the validity or enforceability of any other provision. The parties expressly exclude the application of the United Nations Convention on Contracts for the International Sale of Goods, as amended, replaced or reenacted from time to time.

Minimum System Requirements

- Pentium® 60 Mhz or higher, 16 Mb RAM, Windows® 95 or higher or PowerPC® 90 Mhz, 24 Mb RAM, System 7.5 or higher
- 8-bit Sound Card
- 20 Mb available disk space
- 256 color or higher graphics display
- Standard mouse & keyboard
- 2x speed or better CD-ROM
- Supports TWAIN compatible digital cameras & scanners
- Supports color or monochrome inkjet printers including HP® DeskJet®, Canon® Bubble Jet™, Epson Stylus® and Lexmark®
- Import file formats: Photo CD, TIF, BMP, PICT and JPG

Getting Started

Installing the Software

PC:

- Close all applications.
- Load the CD. Follow "AutoRun" instructions to install.
If not prompted by AutoRun, run the Setup.exe file on the Fashion Magic™ CD-ROM. Click on the Windows® Start menu and choose Run. Then enter D: Setup.exe (where D: is the name of your CD-ROM drive.)
- Review the 'Read Me' file for any important last minute information.
- Restart your computer.

Macintosh®:

- Close all applications.
- Load the CD. If not prompted automatically, double click on the Fashion Magic™ CD-ROM icon. Double click on the TankTop icon.
- Review the 'Read Me' file for any important last minute information.
- Restart your computer.

Un-installing the Software

PC:

Use the Uninstall Icon for the TankTop Kit. From the Start menu, select Programs, and then Fashion Magic™. Choose the Uninstall option.

Macintosh®:

Drag the TankTop Kit directory into the trash.

Opening the Software

The CD must be in the CD-ROM drive of your computer at all times while running the software.

Windows® 95:

Click on START, select PROGRAMS, select Fashion Magic™, then select TankTop Kit.

Macintosh®:

Double-click on the CD icon to open the window, then double click on the TankTop Kit icon.

Getting Around the Software



Create

Print

Assemble

Files

Music

Exit

Help

Create

Choose the layout you want for your designs, then add your own personal touch with pictures and text.

Print

Print out your designs.

Assemble

Finish your project with step-by-step instructions.

Files

Save, Open, Delete, and start New files.

Music

Turn music on/off and set your music preference.

Exit

Quit the program.

Help

Click anytime for detailed instructions and information.


Picking a Layout

Choose which project you would like to make. To work on an iron-on within the project, just click on it. After you finish working on that iron-on, click the Overview button to return to work on others.



Overview: Return to the overview of your project. Use to review your project and to select other design areas to work on.

Layout: Change the design layout. If you're working on a design, you can try new layouts any time.



Background (green)

Picture (purple)

Text (white)

Pick a layout and customize it by clicking on a picture area (purple), border or background area (green) or a text area (white). You can change your layout any time by clicking on the layout button. You'll find layouts that include different combinations of pictures, borders and text. For instance, some layouts may not have a border, or may only include one large text area.

Adding Pictures and Borders

To add a picture, click on a purple picture area in your layout. To add a border or background, click on a green area. While a picture or border area is selected, you'll be able to use the following tools:



Art Library: Select from the cool Fashion Magic™ collection of art! Check out all the different styles in each category.

Import: Add your own photos or artwork. Load BMP, TIF, JGP, PICT or PhotoCD images from your hard drive. If you have a TWAIN compliant scanner or digital camera, you can connect directly to them.

Paint: Add your own special touch to the pictures you've selected for your design. You can even create a painting from scratch.

Stamps: Apply fun stamps to your pictures. Select from the huge collection of original Fashion Magic™ stamps.

Special Effects: Use wild and crazy effects to make your pictures really unique.

While working on your picture you can use the following:

Click and drag in the picture area to move your image and reposition it so it fits the way you like. You can use the following to further adjust your picture.



Importing Pictures:


Photos or other images need to be in one of the following formats: PhotoCD, JPG, TIF, BMP or PICT. Once you have your photos on disk or CD, for easy access copy them into the PHOTOS folder in the Fashion Magic™ folder on your hard drive (these folders are available after the software is installed). You can also select the Scan tab to connect directly to your scanner or digital camera. Images will automatically be saved into the PHOTOS folder. Once you have your images added to your design, you can use the Paint, Stamp, and Special Effects tools to add your own touch.




Modifying Pictures with Paint Tools, Stamps and Special Effects

To modify a picture or background, first select the picture area, and then click the Paint, Stamp or Special Effects buttons.


Paint Tools:



Adding Text to the Design

To add text to your layout, click on a white text box. If you have selected a layout without a text box, you can change layouts anytime by clicking the layout button. Use the text tools to customize your text. You can modify the text and the background color behind the text. If you want the text background to be transparent, choose the .

Text Tools:



Printing Your Designs

It's a good idea to print out a test page in color (using your own paper) to make sure the printer is connected properly and that the ink cartridges are working well. In most cases, the plain paper and normal quality settings should work well. Check your printer user's manual for more information on media and print quality settings available.

Follow the instructions in the software for loading the paper. Adjust the paper guides to make sure the paper feeds in straight. It may be difficult for the printer to pick up the paper when there is only one sheet of paper loaded—be patient and gently guide the paper into the printer if necessary. If your printer has a paper thickness setting, set it for "envelope" or thick paper mode.

Assembling Instructions

Helpful Tips

- You can use the cold peel paper on any cotton or cotton poly blend fabric.
- The ironing surface should be formica or any smooth, hard non-porous surface (other than glass). Don't use an ironing board!
- Total ironing time is approximately 3 1/2 minutes. Always make sure to use very firm pressure and to keep the iron moving constantly.

Preparing your image

Use scissors to carefully trim around the image, coming as close to the printed area as possible.

CAUTION! Adult supervision is recommended for the ironing process.

Ironing Instructions

- 1 Pre-heat your iron on the "highest" dry setting. Allow at least 8 minutes for the iron to heat up.
- 2 Place the garment onto a **wrinkle-free** pillowcase, making sure to center the area of the garment which will receive the printed transfer over the pillowcase.
- 3 Center the transfer, printed side **DOWN** onto the garment.
- 4 Place the iron over both edges of the transfer to set the transfer into place.
- 5 Starting from one edge, push the iron slowly along the long side of the transfer for at least 30 seconds using firm body pressure. Be certain that the iron overlaps **ALL** edges of the transfer.
- 6 Reposition the iron over both edges of the transfer beginning in the opposite corner and repeat step number 5.
- 7 Repeat the ironing steps above.
- 8 Immediately reheat the entire surface by moving the iron in a circular motion over the transfer (for approximately 1 1/2 minutes). Be sure that the flat bottom of the iron

covers the entire surface of the transfer, paying special attention to all edges and corners.

Put the iron aside and wait **one minute before peeling**. Peel the transfer from the fabric, beginning with a corner and using firm, steady pressure.


Washing Instructions

- Use cold water only.
- Set the washer to a low water level.
- Use detergent with color protection.
- Place the garment inside out into the washing machine.
- Dry in dryer under normal settings.

Assembly

Complete assembly instructions are included and animated in the software.

If you like, you can also print detailed instructions from within — the software.



Customer Service and Technical Support

If you have any questions, please contact us for assistance. Our technical support specialists can be reached toll-free at the following number:

In the US, call 1-888-MATTEL9 (1-888-628-8359)

In Canada, call 1-888-MEDIA11 (1-888-633-4211)

In Australia, call 1-902-262-513

(call charged at \$1.50 per minute. A higher rate applies from public or mobile phones)

For a great place to get quick answers to the most commonly asked questions about Fashion Magic™ TankTop Iron-Ons CD-ROM Kit you can also contact Mattel on the World Wide Web at: **<http://www.mattelmedia.com>**

Comments or questions can also be mailed to:

Mattel Consumer Affairs

Tech Support GA 0109

333 Continental Blvd.

El Segundo, CA 90245 USA

When calling from outside the USA, please consult a telephone directory for a Mattel listing.

Fashion Magic™ Credits

Producers: John Cromett, Peggy MacDonald

Associate Producer: Kate Slott

Product Manager: Lisa Dowling

Creative Director: Juliana K. Mills

Animation & Design: Greg Hahn, Mike Kippenhan, Curtis Settino, Teresa Ulrich,

Packaging: Maureen Parrott, Rosie Welch

Programming: Scott Barcik, Greg Cooper, Alex Dommasch, Steven Russell,
Gabriel Watson

Development Manager: Becky James

Localization Coordinator: Anne-Christine Gasc

Product Testing: Billy James, Ken Rueckert, Kim Russell

Music: Sound Dog Studios

Samples: Kelly Feliciano

Special Thanks:

Kenny Bender, Cynthia Berry Meyer, Lauren Berzins, Pam Brew, CreatiCom, Kirk Davis, Michelle Emch, Vada Foster, Kami Gillmour, Debbie Haag, Cheryl Hager, Siri Hammill, Clara Itskovitch, Ronna Katz, Karen Kelly, Amy McPoland, Michele McShane, Michael Mis, Pat Moore, Barry Mroz, Sandy Orum, Kevin Perlas, Katherine Phillips, Jodi Rascoe, Arnie Richards, Ileana Rowe, Tosh Shimoda, Michael Shore, Ben Spayd, John Sullivan, Cathy A. Takemura, Leslee Trussell, Cheryl Vernon, Tim Waters, Steve Weed, Marie Whallon, Christine Wergeles, Nancy Zwiers

MATTEL, INC. 90 DAY LIMITED WARRANTY

Mattel, Inc. warrants to "You" (the original consumer purchaser) that, under normal use, the "Product" (including the software program and the CD-ROM disk on which the software program is recorded and the other items included in the package) will be free from defects in material and workmanship for ninety (90) days from the date of purchase (Your receipt shall be evidence of the date of purchase). This Limited Warranty does not cover damage resulting from accident, misuse, unauthorized modification, or other conduct or conditions outside the control of Mattel, Inc. or its subsidiaries or affiliates (collectively, "Mattel"). If defective, return all contents of this package (including but not limited to the CD-ROM disk, user guide, and all other components of this package), postage prepaid, along with proof of the date-of-purchase, within the ninety (90) day warranty period, for replacement or refund at Mattel's election, to Consumer Adjustment Center, 15930 E. Valley Boulevard, City of Industry, California 91744. Immediately upon Your receipt of any refund, Your license to use the Product (including the software program) is terminated. THE FOREGOING LIMITED WARRANTY IS THE SOLE WARRANTY PROVIDED IN CONNECTION WITH THE PRODUCT AND IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ALL OF WHICH IMPLIED WARRANTIES ARE EXPRESSLY DISCLAIMED. NO ORAL OR WRITTEN INFORMATION OR ADVICE GIVEN BY MATTEL OR ITS SUPPLIERS, DEALERS, DISTRIBUTORS, AGENTS, CONTRACTORS OR EMPLOYEES SHALL CREATE A WARRANTY OR IN ANY WAY INCREASE THE SCOPE OF THIS LIMITED WARRANTY. This Limited Warranty gives You specific legal rights; You may have other rights which vary from state to state. Some states do not allow the exclusion of incidental or consequential damages, or the limitation on how long an implied warranty lasts, so some of the above exclusions or limitations may not apply to You. In that event, or in the event that federal law restrictions apply, such warranties are limited in duration to a period of ninety (90) days from the date of delivery of the Product to the original end user. No warranties apply after that period.

IN NO EVENT SHALL MATTEL'S LIABILITY FOR ANY DAMAGES TO YOU OR ANY OTHER PERSON EXCEED THE PRICE PAID FOR THE PRODUCT, REGARDLESS OF ANY FORM OF THE CLAIM (INCLUDING BUT NOT LIMITED TO BREACH OF CONTRACT, PRODUCT LIABILITY OR NEGLIGENCE).

MATTEL AND ITS SUPPLIERS, DEALERS, DISTRIBUTORS, AGENTS, CONTRACTORS AND EMPLOYEES (COLLECTIVELY, THE "MATTEL GROUP") WILL NOT BE LIABLE FOR ANY LOST DATA, INCIDENTAL, SPECIAL, PUNITIVE OR INDIRECT DAMAGES OR OTHER CONSEQUENTIAL DAMAGES, EVEN IF MATTEL OR ANY OF THE MATTEL GROUP HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. SOME JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU.

For inquiries regarding the Product, please contact Mattel, Inc. at 333 Continental Boulevard, El Segundo, California 90245.

VALID ONLY IN U.S.A.







This CD-ROM contains an advertisement for "QuickTime Pro."

21393-0940

TankTop

CD-ROM KIT

Software
for Girls™

Your use of this
CD-ROM is subject
to a license agreement

21393-0519



EVERYONE



Fashion
MAGIC™


Compatible with Windows® 95 and Macintosh®

MADE IN U.S.A. All Rights Reserved. (See "read Me" file and/or User Guide for additional notices).

© and © 1998 Mattel, Inc., El Segundo, CA 90245 U.S.A.



MoRe Cool Fashion Magic™ CD-ROM Kits!



Tattoos CD-ROM Kit



HairWear 'n Charms CD-ROM Kit

Each sold separately; subject to availability.

This software is provided to you subject to a License Agreement. By opening the CD-ROM jewel case, you are agreeing to be bound by the License Agreement. If you do not agree to be bound by the License Agreement, do not open the CD-ROM jewel case and return the product for a full refund.

© and © 1998 Mattel, Inc., El Segundo, CA 90245 U.S.A. **MADE IN U.S.A.** All Rights Reserved. 21393-0900